

Au. diBoard VoglFuge Painting Instructions



The Association of Wall & Ceiling Industries (AWCI) and the Australian Paint Manufacturer's Federation (APMF) have established recommendations for the finishing of plasterboard.

AS/NZS 2311:2017

As defined in Australian Standard AS/NZS 2311:2017 – Guide to the Painting of Buildings is to deliver the appearance of a uniform surface texture and colour.

Three coat system:

As per AS/NZS 2311:2017 painting of plasterboard must comprise a 3-coat system with a short nap roller. Failure to do so may result in joins being visible and warranty voided.

- Sealer Undercoat x 1
- Top Coat x 2

Atkar recommends:

- Use light coloured paint only
- Do not use gloss paint
- Use a suitable sealer undercoat
- Use good quality paint
- Allow sufficient drying time between coats
- Do not use a spray gun to paint plasterboard
- Apply paint with a short nap paint roller only

Warranty:

Plasterboard and paint systems must be installed and applied strictly in accordance with the manufacturer's specifications and those of the applicable Australian Standards for the performance and integrity including the jointing and paint systems for Au.diBoard VoglFuge to be warranted.

Contact Atkar for further information on 03 9796 3333 or email enquiries@atkar.com.au

www.atkar.com.au

Tel - 03 9796 3333 | Fax - 03 9796 3389 | enquiries@atkar.com.au

Atkar Pty Ltd. 17-19 David Lee Rd, Hallam VIC 3803 Mailing Address: PO Box 1143, Narre Warren MDC Vic 3805

